





## INSTALLATION MANUAL RCS Hy-Q-52



Rev. 20210614  
Printing/Typographical errors and model changes reserved.

**PLEASE RETAIN THESE ASSEMBLY INSTRUCTIONS FOR FUTURE REFERENCE**

If you have any queries concerning the duration and terms of the guarantee, please contact your supplier. We would also refer you to our General Sale and Supply Conditions, which are available on request.

The manufacturer accepts no liability for any damage or injury caused by failure to follow these instructions, or from negligent operation or assembly, even if this is not expressly stated in this instruction manual. In light of our policy of continuous improvement, it is possible that details of the product may differ from those described in this manual. For this reason, these instructions should only be treated as guidelines for the installation of the relevant product. This manual has been compiled with all due care, but the manufacturer cannot be held responsible for any consequences of errors. All rights are reserved and no part of this manual may be reproduced in any way.

We would like to inform you about the fact that this RAVAS product is 100% recyclable on the basis that the parts are processed and disposed off in the right manner.

More information can be found on our website: [www.ravas.com](http://www.ravas.com)



## Table of Contents

<b>1. Introduction</b>	<b>4</b>
<b>2. Warning &amp; Safety measures</b>	<b>4</b>
<b>3. Before the installation</b>	<b>5</b>
3.1 Capacity of the forklift truck	5
3.2 Maximum pressure in the hydraulic system	5
3.3 Battery voltage of the forklift truck	5
3.4 Making the hydraulic system pressure free	5
3.5 The condition of mechanical components of the forklift truck	6
<b>4. Installation</b>	<b>7</b>
4.1 Hydraulics: Installing the T-piece	7
4.2 Hydraulics: Mounting the oil pressure sensor	10
4.3 Mechanics: Installing the position switch holder	11
4.3.a Mechanics: placing stickers to mark reference height	13
4.4 Mechanics: Installing the indicator	14
4.5 Electronics: Mounting the cables	15
4.6 Electronics: Wiring diagrams	16
4.7 Electronics: Connecting the power supply cable	18
4.8 Remove any air from the hydraulic system	18
<b>5. Calibration</b>	<b>19</b>
5.1 Preparing for calibration	19
5.2 Bringing the forklift truck to operating temperature	20
5.3 Operating key functions of indicator	21
5.4 Display functions	21
5.5 Start calibration procedure: first go into the service menu	22
5.6 Set the scale capacity	23
5.7 Change unit label	24
5.8 Set the overload value	24
5.9 Setting the service date	25
5.10 Go into the calibration menu and perform a zero calibration	26
5.11 Execute weight calibration: slow & fast speed	29
5.12 Set zero	30
5.13 Delete a calibration point	30
5.14 Level switch	31
5.14.1 Activate level switch	31
5.14.2 Calibrate level switch	32
<b>6. Parameter settings</b>	<b>33</b>
6.1 Remarks	33
6.2 Parameter settings	34
<b>7. RDC - data transfer</b>	<b>37</b>

# 1. Introduction


This manual describes the installation of the RCS Hy-Q-52. Read this manual carefully. The installer must be informed of the contents of this manual. Follow the contents of the manual precisely. Always do things in the correct order. This manual should be kept in a dry and safe place. In case of damage or loss the user may request a new copy of the manual from RAVAS.

## 2. Warning & Safety measures

When installing the RCS HY-Q-52, please carefully observe the instructions and guidelines contained in this manual. Always perform each step in sequence. If any of the instructions are not clear, please contact RAVAS.



- The installation of the RCS Hy-Q-52 should only be performed by an acknowledged electro and hydraulic technical installer.
- Possible failures to the equipment must be communicated to your installer.
- The equipment should be checked annually by your installer.
- Always follow the safety measures concerning the forklift - or stacker truck accurately.



Should you have any further questions after reading this manual then you can contact us at:

**RAVAS Europe B.V.**  
Toepadweg 7  
Postbus 2023  
5300 CA Zaltbommel  
Nederland

Phone: +31 (0)418-515220  
Fax: +31 (0)418-515320  
Internet: [www.ravas.com](http://www.ravas.com)  
Email: [info@ravas.com](mailto:info@ravas.com)  
Changes reserved

### 3. Before the installation

Before you start the installation, check the following points on the forklift truck:

#### 3.1 Capacity of the forklift truck

The RCS Hy-Q-52 can be installed on forklift trucks with a capacity of maximum 99 ton.

#### 3.2 Maximum pressure in the hydraulic system

The RCS Hy-Q-52 will operate optimally at an oil pressure up to 350 bar.


#### 3.3 Battery voltage of the forklift truck

The most common voltages for forklift trucks are 12, 24, 48 and 80 VDC. The RCS Hy-Q-52 operates on 12 Vdc and always has a DC-DC power converter built in, which allows 9-100 V DC input.


#### 3.4 Making the hydraulic system pressure free

Before installation of the RCS Hy-Q-52 the hydraulic system of the forklift truck must be pressure free. There are two ways to do this:

Option 1: Place the forks on the ground in their lowest position and make the hydraulic system pressure free, by tilting the mast forwards. Be sure the chain is slack!



Option 2: Lift the forks and position them on top of a supporting surface. Make the hydraulic system pressure free, by lowering the lifting cylinder into its lowest position. Be sure the chain is slack!







### 3.5 The condition of mechanical components of the forklift truck

Find a suitable position for the indicator:

After installation of the RCS Hy-Q-52 system on the forklift truck, the weighing system is part of the truck. In particular the mechanical parts of the forklift truck, such as the mast, mast roles and bearings, will influence the accuracy of the weightings. For this reason it is important that these components are in good condition:

- no local wear in the mast of the forklift truck
- clean the system
- good lubrication of the mast and chains
- regular maintenance so that the condition of the system is constant
- when lifting and lowering the forks no whistling and cracking sounds from the mast




## 4. Installation

### 4.1 Hydraulics: Installing the T-piece



We recommend that the installation of the sensor in the hydraulic system of the forklift is performed by an authorized lift truck dealer.

- Ensure that there is no pressure on the main cylinder line.
- The sensor is mounted with a T-piece in the high-pressure hose, between the valves and the main lifting cylinder.
- The connection on the sensor is G $\frac{1}{4}$ " BSP male.
- Protect the cable from moving, sharp or warm parts with the supplied protective cover.
- Mount the T-piece so that the sensor and the cable connection are pointing downwards. This will prevent air getting into the sensor.

OK




WRONG



**Choose a place where you can mount the sensor:**

- Mount the sensor in the pressure hose that steers the main lifting cylinder. In most cases there is one cylinder which moves the carriage plate. The sensor is mounted as close to the cylinder as possible.
- If the pressure hose splits to multiple cylinders, the sensor has to be mounted before the split.
- Do not mount the sensor too close to the engine. Large differences in temperature can influence the accuracy of the system.
- If the truck is used intensively, a piece of pipe or hose of  $\pm 50$  cm can be mounted between the sensor and the T-piece. The sensor is sensitive to temperature differences. If the moving oil becomes warm, the standing oil in this pipe or hose will remain cool and the sensor will not be effected by temperature differences.
- Place the sensor close to the cylinder. There is often more room there and it is easier to reach.
- Choose, if possible, a place to mount the sensor where there are the least steering and safety valves between the sensor and the cylinder.


## Type A: 1 central cylinder



Mount the T-piece into the delivery line of the truck near the cylinder for the diversion of the pressure to the RCS Hy-Q-52.




## Type B: 2 cylinders on both sides



Mount the T-piece into the delivery line of the truck near the cylinder for the diversion of the pressure to the RCS Hy-Q-52.

## 4.2 Hydraulics: Mounting the oil pressure sensor




### 4.3 Mechanics: Installing the position switch holder


The position switch holder and magnet contain the following parts:

1. 1 magnet, to be installed on the carriage plate (moving part)
2. 1 profile with 2 reed switches inside, to be installed on the mast (fixed part)

The distance between the magnet and the switches should be in the range of 5-20mm.




The magnet and lowest switch should face each other when the forks are about 40cm from the ground.




Place the magnet at a location that is free from obstacles all the way up and down the mast.

Decrease the area on the carriage plate where the magnet will be mounted.


The magnet holder can be installed on the carriage plate with the self-adhesive tape or bolts.



Degrease the mast where the switches will be placed.




The holder with switches inside can be mounted on the mast with self-adhesive tape or bolts.




Mount the holder with switches on the outside of the mast.

Note: The cable outlet must be positioned downwards.




Align the lowest switch of the holder with the magnet; there should be 5-20mm clearance in between.



Lift the forks 20 cm, so the magnet is positioned in front of the upper switch.

Align the top switch with the magnet; there should be 5-20mm clearance in between and fix the holder.




#### 4.3.a Mechanics: placing stickers to mark the reference height - optional

Three yellow triangular stickers are supplied with this kit. Two of these stickers are placed on the mast and one on the carriage plate. The arrow stickers are used to mark the reference height.

Note:


- Make sure the driver can see all three stickers;
- The sticker on the carriage plate must be placed in the proximity of the magnet (1);
- The top sticker on the mast must be placed 10cm above the beam with the switches (2);
- The bottom sticker must be placed 10cm below the beam with the switches (3).



## 4.4 Mechanics: Installing the indicator


Position of the indicator:

1. at the cabin's roof.
2. on the right side of the cabin, mounted onto a side-rail.
3. on the dashboard.



The indicator should be easy to reach and read!

Installing the indicator



## 4.5 Electronics: Mounting the cables

Two cables should be mounted:


- cable for the oil pressure sensor
- cable for the position switches

Keep the cable out of sight as much as possible, this keeps the system tidy and it minimizes the possibility of damage to the cable.

It may be necessary to thread the cable through small openings, openings through which the 18mm connector does not fit. In that case disconnect the cable at the indicator.

The system is supplied with a protective cover for the cable. This can be used when:


- the cable is near parts of the lift truck that become hot;
- the cable is mounted near moving parts.



16




## 4.6 Electronics: Wiring diagram speed and level switch holder with sensor distance 300mm



This wiring diagram can be found in a larger size on [MyRAVAS.com](http://MyRAVAS.com).

## 4.7 Electronics: Connecting the power supply cable




### Arrange power supply from the truck

The standard RCS Hy-Q-52 indicator is equipped with an internal 12-100VDC power regulator so can be connected to a 12 to 100VDC power supply only.


## 4.8 Remove any air from the hydraulic system

Bring the forks to maximum height twice to remove any remaining air from the hydraulic system.








## 5. Calibration



### 5.1 Preparing for calibration



Recommended calibration weight:  
 $M1 = \pm 2/3$  of the truck's lifting capacity  
EXAMPLE : 2.2t truck  $\Rightarrow M1 = 1500$  kg



## 5.2 Bringing the forklift truck to operating temperature



### 5.3 Operating key functions of indicator




### 5.4 Display Functions

<b>kg</b>	Display shows weight in kilograms
<b>lb</b>	Display shows weight in pounds
<b>NET</b>	Display shows net weight
<b>TARE</b>	Display shows tare weight
<b>M</b>	Display shows subtotal memory active
<b>Too fast</b>	Move forks slower
<b>Too slow</b>	Move forks faster
<b>Try constant speed</b>	Operate the forks with a more constant speed
<b>Zero out of range</b>	Make sure the truck is unloaded while setting a new zero
<b>Out of level</b>	Make sure the mast is vertical
<b>Bad calibration</b>	no calibration has been done

## 5.5 Start calibration procedure: first go into the service menu


1

On/ Off  
switch



Switch on the indicator by pressing the On/Off button.

2



Press the arrow down 2 times to scroll through the buttons.


3



Press the settings symbol.




4



Now press 'Service Menu'.



5



Enter the password (5220)  
and confirm with enter.

6




You are now in the service menu.

## 5.6 Set the scale capacity


It is important to set the scale capacity according to your forklift truck's capacity because some other parameters like zero tracking and display unit will change accordingly.

1




Select 'Weigher' in the service menu.

2



Select 'Settings'.

3



Select 'Scale capacity'.

4



Select the correct scale capacity (as shown on the indicator's machine sticker) and confirm with enter.


### Truck capacity.

<1.000 kg	select 1.000
1.001-2.500 kg	select 2.500
2.501-5.000kg	select 5.000
5.001-10.000kg	select 10.000
10.001-20.000kg	select 20.000
20.001-50.000kg	select 50.000
50.001-100.000kg	select 100.000

## 5.7 Change unit label


**Note:** The calibration value does not change accordingly. For lb to be displayed you need to perform a new calibration.

1



Select 'unit label'.


2



Choose your preference kg or lb and press 'enter'.

## 5.8 Set the overload value

1



The overload setting determines when the load bar in the display shows overload.

2



Go to 'weigher / settings' and select overload. Enter your truck's capacity here. You can find it on the trucks load diagram.

**Note:** If the option 'overload buzzer' is included in the system, this setting is also the set point for the buzzer.






## 5.9 Setting the service date


In the very rare situation that the indicator is not used for more than a year or if the calibration is done with the wrong time and date, you might get a yellow display on the indicator and the message that service is recommended. However, under these circumstances service is not needed. To restore or to avoid this message you need to switch the service date off.

1



Yellow screen appears on startup. Press 'OK' to skip the message.


2



Enter the service menu, see paragraph 1.4. Select consecutively Weigher - Calibration - Advanced.


Now select 'Service date'.

3



The Service date is set to 'On'. Press 'Off'.


4



Confirm with Enter.


## 5.10 Go into the calibration menu and perform a zero calibration

1



Go to 'service menu / weigher' and select calibration.


2



Calibrate as suggested by the yellow hand. Start with 'Cal: Zero'.


If a calibration is already done (a green tick in front of a Cal point indicates this) and you wish to remove that, press 'Advanced', and select 'Calibration reset'. Confirm by pressing 'OK'.

3



**ZERO CALIBRATION – SLOW:**  
Place empty forks in lowest position and press the key that is suggested by the hand.

4



Lift the forks with constant speed until the yellow arrow up disappears.


Try to approach a speed of 15 cm/s.  
12.5cm/s-17.5cm/s is acceptable \*  
(\*see note on next page)

5



The indicator will show the speed and sensor signal.  
- If speed was to fast or too slow, lower the forks and try again, no buttons have to be operated.  
- If speed was OK, press 'Save'.

6




The first point is saved and the yellow 'Down slow' and the hand suggest which point to do next.


\* NOTE: Plus or minus 2.5cm/s is acceptable.

If this is technically impossible with the truck, then change the parameters for minimum speed and maximum speed first. You can do this via the 'settings' button.

After this you have to do the calibration points that are already done again.




7




Lower the forks with +/- 15 cm/s.

8




If the speed was within the green range, press 'Save'.

9



Continue with the next suggested calibration point: 'Up fast'.

10




Lift the forks with +/- 30 cm/s.

11




If the calibrated speed is correct press 'Save'.

12




Continue with the next suggested calibration point: 'Down fast'.

13




Lower the forks with +/- 30 cm/s.

14



If the speed was within the green range, press 'Save'.


15



All zero calibration points are done and marked with a green tick.

Press 'Back'.


16



Continue with the weight calibration. See instructions in the next section.

## 5.11 Execute weight calibration: slow & fast speed

1




Select 'Cal:weight'.

2



Enter the weight of the load you are going to use to calibrate and confirm with 'Enter'.

3



Pick up the load before you start the calibration. Select 'Up slow'.

4



Repeat steps 4 t/m 16 of the zero calibration instructions.

5



When the weight calibration is completed press 'Back' and return to the weighing mode.


6



Before testing the weighing function, check the zero point first. After the calibration it sometimes doesn't show zero.


## 5.12 Set zero

1



When the screen doesn't show zero, set zero manually. Press the zero button.

2




Follow the instructions on the display.

## 5.13 Delete a calibration point


Only do this if you wish to re-calibrate.

1




Select the 'Calibration' menu.

2




Select 'Advanced'.

3



Select 'Calibration reset'.

4




Confirm with 'OK'.

## 5.14 Level switch


### 5.14.1 Activate level switch

1




In the service menu select 'HyQ settings'.

2




In the HyQ settings scroll down until 'Level switch' and select it.

3



The level switch is standard set to 'Not Active'.

4




Select 'Active' to activate the level switch.

Then press 'Back' 3x to return to the weighing mode.


## 5.14.2 Calibrate level switch

1




In the service menu select 'Weigher'.

2




Then select 'Calibration'.

3



Select 'Advanced'.

4



Select 'Calibrate level switch'.

5


**NOTE: First place the mast of the lift truck in vertical position!**



Press 'OK'.

The vertical 'level' (position) is being saved.

6



Press 'Back' 4x to return to the weighing mode.



## 6. Parameter settings

### 6.1 Remarks

Go into the parameter settings via the Service menu, as described in Chapter 5.5, steps 1-7.

For the list with parameter settings see the next pages.

Before using the RCS Hy-Q-52 indicator, ensure that the parameters have been set correctly.

---

## RCS Hy-C

34

<ul style="list-style-type: none"> <li>Calibration           <ul style="list-style-type: none"> <li>Cal. Zero               <ul style="list-style-type: none"> <li>Calibrate zero</li> <li>Slow Up                   <ul style="list-style-type: none"> <li>Calibrate zero, forklift direction slow up</li> </ul> </li> <li>Slow Down                   <ul style="list-style-type: none"> <li>Calibrate zero, forklift direction slow down</li> </ul> </li> <li>Fast Up                   <ul style="list-style-type: none"> <li>Calibrate zero, forklift direction fast up</li> </ul> </li> <li>Fast Down                   <ul style="list-style-type: none"> <li>Calibrate zero, forklift direction fast down</li> </ul> </li> <li>Settings                   <ul style="list-style-type: none"> <li>Minimum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> <li>Maximum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> </ul> </li> </ul> </li> <li>Cal. Weight               <ul style="list-style-type: none"> <li>Calibrate Span</li> <li>Cal point 1                   <ul style="list-style-type: none"> <li>Slow Up                       <ul style="list-style-type: none"> <li>Calibrate span, forklift direction slow up</li> </ul> </li> <li>Slow Down                       <ul style="list-style-type: none"> <li>Calibrate span, forklift direction slow down</li> </ul> </li> <li>Fast Up                       <ul style="list-style-type: none"> <li>Calibrate span, forklift direction fast up</li> </ul> </li> <li>Fast Down                       <ul style="list-style-type: none"> <li>Calibrate span, forklift direction fast down</li> </ul> </li> <li>Settings                   <ul style="list-style-type: none"> <li>Minimum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> <li>Maximum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> <li>Reference weight                       <ul style="list-style-type: none"> <li>Change the calibrations reference weight</li> </ul> </li> </ul> </li> </ul> </li> <li>Cal. View               <ul style="list-style-type: none"> <li>View calibration points</li> </ul> </li> <li>Advanced               <ul style="list-style-type: none"> <li>Number of Cal. Points                   <ul style="list-style-type: none"> <li>1,2,3,4</li> </ul> </li> <li>Manual                   <ul style="list-style-type: none"> <li>Manually adjust calibration points</li> </ul> </li> <li>Calibration reset                   <ul style="list-style-type: none"> <li>Reset all calibration points and settings to factory defaults</li> </ul> </li> <li>Calibrate level sensor                   <ul style="list-style-type: none"> <li>Perform a new level sensor nearside position calibration</li> </ul> </li> <li>Settings                   <ul style="list-style-type: none"> <li>Minimum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> <li>Maximum Speed                       <ul style="list-style-type: none"> <li>1-100</li> </ul> </li> </ul> </li> </ul> </li> </ul> </li></ul></li></ul>	<ul style="list-style-type: none"> <li>Hy-Q settings           <ul style="list-style-type: none"> <li>Sensor Distance               <ul style="list-style-type: none"> <li>Set distance between need switches</li> </ul> </li> <li>Speed Calibration               <ul style="list-style-type: none"> <li>Activate speed calibration</li> </ul> </li> <li>Minimum Speed               <ul style="list-style-type: none"> <li>Set minimum speed for correct weighing (blue screen)</li> </ul> </li> <li>Maximum Speed               <ul style="list-style-type: none"> <li>Set maximum speed for correct weighing (blue screen)</li> </ul> </li> <li>Easy Barwidth               <ul style="list-style-type: none"> <li>Set optional barwidth for easy mode</li> </ul> </li> <li>Weighing direction               <ul style="list-style-type: none"> <li>Set direction of measurement, easy mode needs to be active to use this.</li> </ul> </li> <li>Max. time Up &gt; Down               <ul style="list-style-type: none"> <li>Max time between Up and Down Weighing</li> </ul> </li> <li>Sensor Blind Time               <ul style="list-style-type: none"> <li>Time that multiple inputs of one must sensor are being ignored</li> </ul> </li> <li>Arrow Hold Time               <ul style="list-style-type: none"> <li>Time that the arrow up keeps flashing after passing the upper sensor</li> </ul> </li> <li>Level sensor               <ul style="list-style-type: none"> <li>Level Function                   <ul style="list-style-type: none"> <li>Set the correction sensor mode</li> </ul> </li> <li>Switch off angle                   <ul style="list-style-type: none"> <li>Set the switch off angle</li> </ul> </li> </ul> </li> <li>On screen type plate               <ul style="list-style-type: none"> <li>Error a on screen type plate if preferred</li> </ul> </li> </ul> </li> <li>Communication           <ul style="list-style-type: none"> <li>Printer settings               <ul style="list-style-type: none"> <li>Line-feed                   <ul style="list-style-type: none"> <li>adjust line feed after print out</li> </ul> </li> <li>Header                   <ul style="list-style-type: none"> <li>Add header to print out</li> </ul> </li> <li>Footer                   <ul style="list-style-type: none"> <li>Add footer to print out</li> </ul> </li> </ul> </li> </ul> </li> </ul>
---	--

<ul style="list-style-type: none"> <li>Bluetooth 4.0 on-board           <ul style="list-style-type: none"> <li>Protocol Set the operation protocol PC</li> <li>Info PC</li> </ul> </li> <li>RS232 on-board           <ul style="list-style-type: none"> <li>Protocol Set the operation protocol None/PC/Printer</li> <li>Stopbits 12 1</li> <li>Databits 7/8 8</li> <li>Parity None Odd/Even/Mark/Space</li> <li>Baudrate 1200/2400/4800/9600/19200/38400/57600/115200 9600</li> </ul> </li> <li>USB on-board</li> <li>COM 10</li> <li>Hardware           <ul style="list-style-type: none"> <li>Port settings               <ul style="list-style-type: none"> <li>Protocol Select the installed hardware None/WiFi board</li> <li>Protocol                   <ul style="list-style-type: none"> <li>Scale id Set the operation protocol None/ASCII/Printer/RDC</li> <li>Mode As/Back automatically according to logic board sn. on</li> </ul> </li> <li>Stopbits 12 1</li> <li>Databits 7/8 8</li> <li>Parity None Odd/Even/Mark/Space</li> <li>Baudrate 1200/2400/4800/9600/19200/38400/57600/115200 9600</li> </ul> </li> <li>COM 20               <ul style="list-style-type: none"> <li>Hardware                   <ul style="list-style-type: none"> <li>Port settings                       <ul style="list-style-type: none"> <li>Protocol Select the installed hardware None/WiFi board</li> <li>Protocol                           <ul style="list-style-type: none"> <li>Scale id Set the operation protocol None/ASCII/Printer/RDC</li> <li>Mode As/Back automatically according to logic board sn. on</li> </ul> </li> <li>Stopbits 12 1</li> <li>Databits 7/8 8</li> <li>Parity None Odd/Even/Mark/Space</li> <li>Baudrate 1200/2400/4800/9600/19200/38400/57600/115200 9600</li> </ul> </li> </ul> </li> </ul> </li> </ul> </li></ul>	PC	PC
Power settings <ul style="list-style-type: none"> <li>Power save mode               <ul style="list-style-type: none"> <li>Dim timer 0-5800 s 60</li> <li>Sleep timer 0-3600 s 300</li> <li>Deep sleep timer 0-1440 h 8</li> </ul> </li> <li>Power supply               <ul style="list-style-type: none"> <li>Set the power supply source Touch supply/ Li-ion 4.8V/ 12V/ 24V/ Custom Touch supply</li> </ul> </li> </ul>		
Service help <ul style="list-style-type: none"> <li>Check calibration points (read only)               <ul style="list-style-type: none"> <li>View all in NR</li> <li>Error and overload logging database</li> <li>Screen on which sensor inputs can be checked</li> </ul> </li> </ul>		
Reset <ul style="list-style-type: none"> <li>Reset settings               <ul style="list-style-type: none"> <li>Reset Calibration                   <ul style="list-style-type: none"> <li>Reset only the settings, calibration is kept in touch. (not scale type software)</li> <li>Reset only the calibration, settings are kept in touch</li> <li>Select the scale type software H<sub>2</sub>Q/HPT</li> </ul> </li> </ul> </li> </ul>		
Scale type software		H <sub>2</sub> Q

## 7. RDC - data transfer using WiFi to PC/server using RAVAS RDC software

In 'SERVICE' / 'COMMUNICATION' / 'COM10 '

Select 'RDC'

- Mode ACK / NACK >>> should be 'ON'
- Scale id >>> here you can enter a 3 digit PIN code

This PIN code is used as scale ID and will be used in the CSV file to determine which indicator has sent the data – please make sure you use a unique number

The RDC software will list this number and at the PC you can enter an alias for this scale nr. (for example: 'Forklift 24').

Note: make sure that your Xpico settings are correct!

In 'Tunnel settings' you need to enter the static IP address of the server and use port number 5555 – see also the Xpico240 or XpicoWi-Fi manual.

---